

TM-4100GE Progressive Scan Shutter Cameras

Operation Manual



PULNiX

Notice

The material contained in this manual consists of information that is proprietary to JAI PULNiX, Inc., and may only be used by the purchasers of the product. JAI PULNiX, Inc. makes no warranty for the use of its product and assumes no responsibility for any errors which may appear or for damages resulting from the use of the information contained herein. JAI PULNiX, Inc. reserves the right to make changes without notice.

Microsoft, Windows XP, Windows 2000, Windows 98, Windows NT, and Windows Explorer are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Warranty

For information about the warranty, please contact your factory representative.

Certifications

<u>CE Compliance</u>

The TM-4100GE camera has been certified to conform to the requirements of Council Directive 89/336/EC for electromagnetic compatibility and to comply with the following European Standards:

Immunity: EN 55024: 1998 + A1: 2001 + A2: 2003 Emissions: EN 55022: 1998 + A1: 2000 + A2: 2003

All JAI PULNiX products bearing the CE mark have been declared to be in conformance with the applicable EEC Council Directives. However, certain factory-installed options or customer-requested modifications may compromise electromagnetic compatibility and affect CE compliance. Please note that the use of interconnect cables that are not properly grounded and shielded may affect CE compliance.

Contact JAI PULNiX Applications Engineering Department for further information regarding CE compliance.

FCC

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area may cause harmful interference, in which case the user will be required to correct the interference at his own expense.

WARNING

Changes or modifications to this unit not expressly approved by the party responsible for FCC compliance could void the user's authority to operate the equipment.

TM-4100GE Series Operation Manual JAI PULNiX, Inc. 625 River Oaks Parkway San Jose, CA 95134 Tel:(408) 383-0300 Tel:(800) 445-5444 Fax:(408) 383-0301 E-mail: imaging@jaipulnix.com www.jaipulnix.com



TM-4100GE Progressive Scan Cameras

Table of Contents

1	Sof	ftware Introduction.	.1
	1.1	Scope of the Document	1
	1.2	Related Documents.	
	1.3	Gigabit Ethernet Camera Interface	1
	1.4	Software Installation.	
		1.4.1 Before Installing the GigE Series Camera-SDK Software	
		1.4.2 Installing the Software	
		1.4.3 Installing the Software	
		1.4.4 Uninstalling the Software	
		1.4.5 Quick-Start	4
2	Co	nnectors	.7
-		Power and Signals Connector.	
		Ethernet.	
3	Co	nfiguring the TM-4100GE Camera	.9
	3.1	Setup	
	3.2	Configuring the Imager	11
		3.2.1 GUI Features	
	3.3	Configuring the Internal Frame Grabber	
	3.4	Modes	
		3.4.1 Check the Current Camera Setting	
		3.4.2 Exposure Control	13
		3.4.3 Scan Mode	
		3.4.4 Gain Settings	
		3.4.5 The Gain	
		3.4.6 Look-Up Table	
		3.4.7 Memory Pages 3.4.8 Free-Running Mode	
		3.4.9 Externally Triggered	
		3.4.10 Internally Triggered	
		3.4.11 Save/Restore Settings to Your Hard Disk.	
		3.4.12 White Balance Control (Color Versions Only)	
		3.4.13 Main Menu: "Option"	
		3.4.14 Version	
		3.4.15 Exit	19
4	Sig	nal Handling	.20
		Camera Inputs.	
		Camera Outputs	
		GPIO Control Block	
		GPIO Label Table.	
	4.3	Pulse Generators	23
5	Gig	gE Series Camera Serial Commands	.26
6	Hai	rdware Introduction	.31



		Product Description31Features.32
7	7.1	tallation.34Getting Started.347.1.1 Unpacking Instructions.347.1.2 Components.347.1.3 Accessories and Options.34
	7.2	Camera Setup357.2.1 Heat Dissipation357.2.2 Connector Pin Configurations357.2.3 Power Supplies and Power Cable Setup367.2.4 Attaching the Camera Lens387.2.5 Adjustable Back-Focus38
8	Op	eration
	8.1	Progressive Scanning
	8.2 8.3 8.4 8.5 8.6	Bayer Color Filter (Color Versions)418.2.1 Color Filter Array418.2.2 Bayer Color Filter Array (CFA)418.2.3 Starting Pixel Configuration428.2.4 Sync and Data438.2.5 Camera Functions438.2.6 Interpolation Software448.2.7 Color Interpolation44Electronic Shutter44Integration45External Sync45Asynchronous Reset458.6.1 Async No Shutter46
		8.6.2 Internal Shutter Speed Control 47 8.6.3 External VINIT With Pulse Width (No-Delay Shutter) and ROI (Read-out Inhibit) 48
		Dynamic Range Control498.7.1 Programmable Look-Up Table (LUT) and Knee Control50
	8.8	Camera Timing Charts
9	Tro	ubleshooting
		Problems and Solutions559.1.1 Symptom: No Video559.1.2 Symptom: Dark Video559.1.3 Symptom: Non-Synchronized Video55
10		pendix .57 Specifications .57 10.1.1 TM-4100GE Physical Dimensions .58 10.1.2 Spectral Response .59



List of Tables

TABLE 1.	Hirose Connector, Pin Assignment	. 7
TABLE 2.	GPIO Look-Up Table Input Labels	
TABLE 3.	GPIO Look-Up Table Output Labels	
TABLE 4.	TM-4100GE Command List	
TABLE 5.	18 Bytes Status Report.	
Table 6.	12-Pin Connector	35
TABLE 7.	Scan Mode	41
TABLE 8.	Electronic Shutter Speeds	45
TABLE 9.	Video Output	53
TABLE 10.	External HD Locking and External VD Reset.	54
TABLE 11.	Async Reset	54
TABLE 12.	TM-4100GE Camera Specifications Table	57





PULNIX®

List of Figures

Figure 1.	Scanning for Drivers	
Figure 2.	Intel Pro Install Choices.	3
FIGURE 3.	Change and Remove Buttons.	4
FIGURE 4.	Network Device Finder Window	5
FIGURE 5.	Select Camera Window	5
FIGURE 6.	TM-4100GE Back Panel Connectors	7
FIGURE 7.	HR10A-10R-12P	8
FIGURE 8.	Ethernet GigE Socket.	8
FIGURE 9.	Camera Interface Application Dialog Box	9
FIGURE 10.	Advanced Configuration Window	
FIGURE 11.	Integrated GigE Camera Software	
FIGURE 12.	Advanced Configuration - Port Communication	13
FIGURE 13.	Exposure Control	13
FIGURE 14.	Mode Control Pull-down	14
FIGURE 15.	Shutter Speed	14
FIGURE 16.	Scan Mode	
FIGURE 17.	Offset Level	15
FIGURE 18.	Look-Up Table	16
FIGURE 19.	Memory Pages	
FIGURE 20.	White Balance Control Settings.	18
FIGURE 21.	GE Camera GPIO Control Block.	21
FIGURE 22.	GPIO Look-Up Table.	
FIGURE 23.	The GPIO Configuration	22
FIGURE 24.	Pulse Generator Page	25
Figure 24.	12-Pin Connector Pinouts	
Figure 25.	GigE Ethernet Connector	36
FIGURE 26.	12P-02S Interface Cable (optional)	37
FIGURE 27.	Back-Focus Set-Screw Locations	39
FIGURE 28.	Full Progressive Scan Mode (A)	40
FIGURE 29.	Bayer Color Filter Response	
FIGURE 30.	Example of Color CCD CFA Pattern	
FIGURE 31.	Example of TMC-4100GE (Same as TM-4100GE)	
FIGURE 32.	No-Delay Shutter	48
FIGURE 33.	Read-Out Inhibit	
FIGURE 34.	Physical Dimensions	58
FIGURE 35.	Spectral Response	



PULNiX®

TM-4100GE Software

Operation Manual



1 Software Introduction

1.1 Scope of the Document

This manual describes how to access and use features specific to JAI PULNiX's Gigabit Ethernet camera, the TM-4100GE. The camera's different operation modes are described in the hardware section of this manual, which begins on page 31.

The TM-4100GE series consists of the TM-4100GE (monochrome) and the TMC-4100GE (color). Unless otherwise noted, all information contained in this manual is relevant to both models.

1.2 Related Documents

The appendix contains descriptions of the TM-4100GE camera's internal frame grabber and how to connect the camera. The appendix complements, and should be used in conjunction with the three following documents:

- Cam2Net User's Manual
- Cam2Net IP Device Drivers
- Cam2Net C++ SDK Reference Manual

These documents are part of the GigE software package and are added to your system when the software is installed.

1.3 Gigabit Ethernet Camera Interface

The GigE interface provides an easily connectable, high-bandwidth imaging solution, where video data is sent as IP packets over an industry-standard GigE network.

TM-4100GE Software **PULDIX**®

Point-to-point (unswitched) transmission is up to 100 meters. With Gigabit Ethernet switches, the transmission distance is virtually unlimited.

Note: Refer to the section on time-outs and packets in the *Cam2Net User's Manual* for more information on packet sizes for point-to-point and networked applications.

Communication with a GigE camera is completely transparent to the user, so if you are used to working with Camera Link® or the JAI Cam2Net adapter, you will find it very easy to migrate.

The TM-4100GE camera has internal frame memory, which sends only the actual image data using the Gigabit Ethernet interface.

At the PC, the *Cam2Net Software Development Kit (SDK)* provides a communications interface that maps the RS-232 command channel through the IP link. All commands sent to and received from the camera are transparently routed to/from the host PC via the GigE link.

Refer to the Cam2Net User's Manual for details about network requirements, compatibility, and so on.

1.4 Software Installation

The following instructions explain how to install the JAI PULNiX GigE camera-control software on a PC.

1.4.1 Before Installing the GigE Series Camera-SDK Software

Before installing the JAI PULNiX GigE camera-SDK software, please note the following requirements.

- Your computer must have a Pentium processor running at least 1.4GHZ, and its operating system must be either Microsoft Windows XP Pro or Windows 2000.
- Installation of the software requires approximately 75 MB of free space in your PC hard disk.

1.4.2 Installing the Software

To install the JAI PULNIX GigE camera-SDK software, read and follow the directions included in the document download card. If your computer does not have Internet access, call JAI PULNIX at 1 800 445 5444 to request that the software be sent to you on a CD-ROM.

Install the software using the following steps:

1.4.3 Installing the Software

To install the JAI PULNIX GigE camera-control software, read and follow the directions included in the document download card. If your computer does not have Internet access, call JAI PULNIX at 1 800 445 5444 to request that the software be sent to you on a CD-ROM.

Install the software using the following steps:

1. Open the folder "JAI" and run the IPEngineSDK.exe file to install the Camera Interface Application.

- 2. Open the folder "GigE_Software" and run the setup.bat file. This installs the GigE camera software as part of the Camera Interface Application. It copies the file cycampulnix.dll to the folder C:\Program Files\JAI\Cam2Net\Binaries.
- The program initiates a driver scan. Allow the network card driver installation at this time. (If you cancel the installation for some reason this dialog box can be accessed at a later time; go to "Start" --> "Programs" --> "JAI AS" --> "Launch Driver Installation Tool" to launch the driver install).
- 4. A driver installation tool dialog box displays. Read the message about canceling *found new devices* and then click **"OK"**.

Figure 1. Scanning for Drivers

Driver Installation Tool (x86)				
!	The Driver Installation Tool is about to scan for new hardware. Windows will display a "Found New Hardware Wizard" for every hardware device it finds that does not currently have a driver.			
	Please CANCEL every "Found New Hardware Wizard" while the Driver Installation Tool is running.			

- 5. The Driver Installation Tool dialog box appears with a listing of all NIC cards on the system.
- 6. Right click on the net driver desired for the camera. If the driver is an Intel Pro a high performance option is available for install.

Figure 2.	Intel Pro Install	Choices
-----------	-------------------	---------

Pro1000 Adapters Universal	P Filter Driver	High Memory Driver Dri	vers	
Device Description		Device Class	Location I	nformation
		o Driver o Filter Driver all High Performance IP De all Intel Network Driver Istall Driver	vice Driver	. device 4, functi
	Prop	perties		

- 7. Right click on the net driver desired for the camera.
- 8. Select the desired driver install **"Install High Performance IP Device Driver"** or **"Install Intel Network Driver"**. The network installation options vary, based on the NIC card installed on the

system. A dialog box asks for verification of the selected install. Click "Yes". Follow the instructions on any additional dialog boxes.

- **9.** For information on other network card installs click "Start"-->"JAI A.S"-->"Cam2Net"-->"Documentation"-->"Cam2Net IP Device Drivers". An Acrobat file has instruction to help guide you through the proper install.
- **10.** Go to "**Start**" --> "**Programs**" --> "**JAI AS**" --> "**Cam2Net**" --> "**Launch Coyote application**" to launch the camera control tool.

11.

1.4.4 Uninstalling the Software

To uninstall the JAI PULNiX GigE camera-control software from the control panel, use the following steps:

- 1. Open "Add or Remove Programs" in the control panel.
- 2. Select "JAI Cam2Net" from the lists of the installed software.
- 3. Click the "Change or Remove" button as shown in Figure 1.

FIGURE 3. Change and Remove Buttons

🐻 Add or Rei	nove Programs			×
5	Currently installed programs:	dates Sort by: Name	*	¢
C <u>h</u> ange or Remove	🛥 Dual Tap AccuPixel Software_v2.2 (beta)	Size	3.73MB 🛃	^
Programs	📾 Easy CD Creator 5 Basic	Size	24.37MB	
	Euresys MultiCam 2.9.2			
	🔄, EZiTeacher BW and Color V3.4.13 (Beta 12/21/04)	Size	57.54MB	
Add <u>N</u> ew Programs	Inspector	Size	8.95MB	
-	🔀 Genesis Native Library	Size	67.10MB	
<u> </u>	🥭 Google Toolbar for Internet Explorer	Size	0.69MB	
Add/Remove Windows	🧭 InstallShield for Microsoft Visual C++ 6	Size	1,722.00MB	
Components	🕵 Intel(R) PRO Ethernet Adapter and Software	Size	0.04MB	
	🔛 JAI Cam2Net	Size	75.10MB	
Set Program	Click here for support information.	Used	<u>rarely</u>	
Access and Defaults	To change this program or remove it from your computer, click Change or Rem	nove. Change	Remove	
	A MATLAB Family of Products Release 12	Size	740.00MB	
	🔀 Matrox Imaging Products			

1.4.5 Quick-Start

Use the following quick-start process when the Camera Interface Application is installed on your PC.

- 1. Connect the camera. The Hirose pin layout is shown in Table 1 on page 7. Both the Hirose and the network cable (RJ-45) are illustrated in Figure 6.
- 2. Run the Camera Interface Application.
- 3. Click "Detect." Assign a suitable IP address to the camera. The window shown in Figure 2 appears.

FIGURE 4.	Network	Device	Finder	Window
-----------	---------	--------	--------	--------

🎬 Camera Interface Appli	cation	
File Camera Tools Display	🖳 Network Device Finder	
Device Acquisition External		
Device Information	High-Performance Driver [00:07:E9:15:D4:0A]	
Status Not		
Device Name		
Device Information		
Camera		
- IP Information		
IP address		
IP name (optional):		
MAC ALLOW		

4. Select the appropriate camera from the list, similar to the window shown in Figure 3 and click OK.FIGURE 5. Select Camera Window

Device Information	xternal Configurati	1			
Status	Not connected.		Device ID 0	•	
Device Name	New Device 1			_	
Device Information	Gigabit Etherne	t Device, JAI/Pulnix Camera		_	
Camera			Select camera		
IP Information		- Time oute & Pool	olo		
IP address	192 . 168	🔐 Select Camera 📃 📃	00	ms	
IP name (optional):		Standard CameraLink Camera		ms	
MAC address	00 11 10	JAI PULNX TM-4100GE JAI PULNX TMC-4100GE	<mark>0</mark>	ms	
Adapter ID	00:07:E9:15:		100	ms	
Communication mode	UDP over De		28 🚊]	
Multicasting	Enab				
Setup device IP a	address at conne				
Device Actions		OK Cancel			
Detect Add Detect					

- 5. Go to the "Acquisition" tab and click Start. An image stream should appear.
- 6. Click on **Configure** and open the "GigE Camera Software" dialog box. This is your integrated control software.

Note: the color version (TMC-4100GE) requires color interpolation to be performed in the frame grabber or by using the host computer's CPU. In default mode, the camera supports 2×2 color interpolation. For better color performance, the user can select 3×3 interpolation in the Camera

Interface Application. Go to the "Acquisition" tab and click **Configure**. In the Advanced Configuration Window, select the "Pixel Type" tab. Make sure the camera is set to the proper color space and pixel depth, then click the check-box labeled "Use 3 x 3 Bayer Interpolation" in the "Conversion Options" panel. More information on color interpolation and the color filter array (CFA) can be found in Section 8.2 beginning on page 38 of this manual.




2 Connectors

The camera has two sockets, as shown in Figure 6 below:

- 12-pin Hirose for power, trigger, RS-232 communication and TTL I/O.
- RJ-45 for Gigabit Ethernet.

FIGURE 6. TM-4100GE Back Panel Connectors



These connectors are described in Section 2.1 and Section 2.2 below.


2.1 Power and Signals Connector

The GE camera receives power and signal through a 12-pin Hirose connector. Table 1 lists the pin layout and describes the function of each pin. The table lists the GPIO assignments for the relevant pins. A magnified illustration of each pin's assignment follows in Figure 7 on page 8.

TABLE 1.Hirose Connector, Pin Assignment

Pin #	Definition	Description	GPIO Assignment
1	GND	Power ground	
2	+12V	Power supply in	
3	AGND	Analog ground (video)	
4	Reserved	Reserved	
5	GND	Ground (TTL) - Digital	
6	TTL IN (EXT_TRIG)	INTG IN (CC2 equivalent)	Ю
7	TTL IN (EXT_VD)	HD in (CC4 equivalent)	I1 (can bypass GPIO LUT)
8	TTL OUT (STROBE)	Strobe output	Q0
9	TTL IN (EXT_HD)	VD in (CC3 equivalent)	I2 (can bypass GPIO LUT)
10	RESV	Reserved	
11	TTL IN (INTG_CON)	Reserved	13
12	RESV	Reserved	

FIGURE 7. HR10A-10R-12P



2.2 Ethernet

The GigE socket, marked on the camera's back panel as "GigE," is a standard RJ-45 Ethernet socket. Use at least cat5e UTP cables (Cat6 cables are preferred). If you wish to connect the camera directly to a PC, you must use a cross-over cable. Refer to the *Cam2Net User's Manual* for details.¹

FIGURE 8. Ethernet GigE Socket

 GigE	

^{1.} JAI PULNiX recommends the use of shielded cables to reduce emissions and for CE/FCC compliance. Double-shielded cables will further reduce emissions.



3 Configuring the TM-4100GE Camera

The configuration of your GigE camera consists of two parts:

- The imager configuration (CCD and control circuits)
- The internal frame grabber configuration

The imager can be configured for partial scan, binning, and so on, just like a Camera Link camera. The internal frame grabber is automatically configured for the pixel type, windowing, image size, I/O and so on, by the GigE camera software.

3.1 Setup

If you have a peer-to-peer connection between the TM-4100GE camera and your PC without network switches, your packet size can be the default value (8128 bytes) as shown in Figure 7. However, if you are connecting the TM-4100GE to your PC through a network switch, then you need to know the maximum packet size that your network switch supports. Typically, if your switch supports jumbo packets, then you should keep the packet size to 8128 bytes. If your switch does not support jumbo packets, then you may need to change the packet size to 1440 bytes.

FIGURE 9. Camera Interface Application Dialog Box							
4	Ne	w Device 1 - Coy	rote				
F	File I	Device Tools Displ	ay Help				
	Dev	ice Acquisition Dia	agnostic				
		evice Information					
	9	Status	Connected to devic	e		Device ID 0	•
	0)evice Name	New Device 1				
Notes If compositely a	0	evice Information	Gigabit Ethernet De	evice, JAI/Pulnix Ca	amera, 16 MB of onboard F	RAM	
Note: If you connect the camera through a network switch, you may need to	0	Camera	JAI PULNIX TM-14	05GE		Select	camera
nodify the packet size.		P Information			Time-outs & Packets		
\sim	1	P address	192 . 168 . 2	2 . 254	Command Retries	3	
		mame (optional):			Answer Timeout	1000	ms
	N	MAC address	00 11 1C F0	10 49	First Packet Timeout	0	ms
	4	Adapter ID	00:07: E9:1 5:D4:04	-	Packet Timeout	500	ms
	(Communication mode:	UDP over Device		Request Timeout	5000	ms
		Heartbeat / Multi-targ	get Enable Ser	rial Port Link	Packet Size	8128	-
		Connection Flags.	P	orts	Calculate timeouts		
)evice Actions					
		Detect	Add	Deleti	e Test	Re	econnect

TM-4100GE Software **PULDIX**®

To use the integrated GigE camera software, use the following steps:

- 1. Start the Camera Interface Application. The dialog box shown in Figure 9 appears.
- 2. Click the **Detect** button to detect the device and driver in the "Device Actions" panel.
- 3. Click Select Camera and select TM-4100GE or TMC-4100GE (color) from the camera list.
- 4. Select the "Acquisition" tab and click Configure. The camera configuration dialog box displays.
- 5. Select the "GigE Camera Software" tab. This is the Integrated GigE Camera Software shown in Figure 11 on the next page.

The TM-4100GE camera can operate in either 8-bit or 10-bit digital output mode. The 8-bit/10-bit selection is possible through the GigE integrated software. To select the mode, open the Configure page and select the Pixel Type tab. Under the Pixel Type, select either Grayscale 8, or Grayscale 10. Note that when Grayscale 10, 2 taps is selected, the LUT (Look-Up Table) is not available in this mode.

FIGURE 10. Advanced Configuration Window

onfiguration - Advar	nced		×
Device Features Image Settings			Camera Software
Pixel Type			
Color space	Grayscale		•
Pixel Depth	8 bits	Tap Quantity 1	•
Flags	🔲 Normalized 🔲 Packed 🔲 Int	erlaced Format Info	
Dual Output Format	2-taps, Interleaved		-
Matching Pixel Types:			
Grayscale 8-bits			-
Current Pixel Type ID:	000000000010001h	Available converters.	
Conversion Options			
Starting Bayer Pattern	Bayer Pattern GRBG		-
🗖 Automatically adjus	t Bayer pattern based on the window off	sets	
🔲 Use 3 🗙 3 Bayer In	terpolation (more CPU intensive).		
🔲 Invert fields when a	de-interlacing interlaced image data		
Show advanced config	guration pages	OK Close	e Apply



3.2 Configuring the Imager

To configure the TM-4100GE's imager, use the integrated GigE camera software that is part of the Cam2Net Camera Interface Application. You can also use the dual-tap AccuPiXEL GigE control tool, but that will not update any internal grabber settings. "Hardware Introduction" on page 27 of this manual contains a description of the different image settings of the camera.



Configuration
Timestamp GPIO Look-up Table GPIO Function Select GPIO Control Bits Grabber Settings Image Settings Counter Debouncers Pulse Generator CameraLink Settings GigE Camera Software Serial Free Form
Exposure Control Gain Settings Offset Level Mode A(dB) 2.97 21.96 Manual Shutter 6.84 - - Shutter Speed B(dB) 2.97 21.96 Direct Shutter Value 6.84 - - 2048 H (Note:On Channel Balance, channel Balance) Guil: 2.02 Release Channel B aligns to channel A) Channel Balance Camera FW: TM4100 CPU Ver2.3 Jul 11, 2005
Scan Modes Partial Scan Area A - 2048x2048(full) Binning Ix1(No Binning) Pixel Output: 2048 x 2048
OK Close Apply

3.2.1 GUI Features

You can control the following camera functions using the integrated camera software.

- Shutter Speed and Mode
- Scan Mode
- Gain Control
- Offset Level
- Memory Pages
- LUT (Look-Up Table) Control

3.3 Configuring the Internal Frame Grabber

The integrated camera software updates the internal frame grabber settings automatically. In addition, because the internal frame grabber configuration is independent of the imager configuration, you can set up (that is, "window") the internal frame grabber separately, for example, the Image Settings tab in the integrated camera software. This has the added benefit of reducing unnecessary traffic on the GigE network, hence freeing bandwidth for other cameras.

3.4 Modes

This section includes examples of various types of setup actions available through the camera configuration dialog box.

3.4.1 Check the Current Camera Setting

You can manually send camera commands from the "Serial Free From" tab of the Configuration window shown in Figure 12. Use the serial port and click the "CR" check box. Enter :RPST and click **Send** to get the current camera setting. For detailed information about the current camera setting, refer to Table 4 on page 26.



Configuration	? 🛛
Grabber Settings Image Settings Timestamp GPIO Look-up Table GPIO Fund GPIO Control Bits Pulse Generator CameraLink Settings GigE Camera Software Seria	tion Select
Send as: ASCII Hexadecimal Configure Serial Port	
:RPST Send Append: CR LF NULL Other hex Delay between bytes 0 ms	
Receive Receive as: © ASCII © Hexadecimal Clear Log	
>:RPST0:oRR00DE002000DE00218000786EFFFFFFFFFFFFFFFFFFFFFFFF000001F30	

FIGURE 12. Advanced Configuration - Port Communication

3.4.2 Exposure Control

In Exposure Control, under the GigE Camera software tab, shown in Figure 13, you can specify the shutter mode and set the shutter speed and direct shutter values.

FIGURE 13. Exposure Control

Exposure Control Mode
Manual Shutter 📃 🗨
Shutter Speed
0 🔹
Direct Shutter Value

Page 14 Configuring the TM-4100GE Camera

Shutter Mode

Use the pull-down menu shown in Figure 14. to select from Manual or Async mode.

FIGURE 14. Mode Control Pull-down

Mode	
Manual Shutter	•
Manual Shutter	
Manual Shutter Async Shutter	

Shutter Speed

The shutter speed setting, shown in Figure 15, allows you to select the specific shutter speed for manual shutter and Async shutter. Manual shutter speed 0 is No Shutter mode; Async shutter speed 0 is Async - No Shutter mode; Async shutter speed 9 is Async - No Delay shutter mode (pulse width control). Direct Shutter allows you to select shutter speed for direct shutter count by the video line. Please note that manual shutter 1 and 2 are not available in scan mode B and D.

FIGURE 15. Shutter Speed

Shutter Speed	
0	-
Direct Shutter V	alue

3.4.3 Scan Mode

The TM-4100GE camera has full and partial scan modes as shown in Figure 16. The partial scan area allows you to select the different scan lines. When the scan area starts from an odd line, for a color camera, an offset of 1 is added in the vertical direction. The TM-4100GE camera has no binning modes.

FIGURE 16. Scan Mode

Scan Modes Partial Scan Area
A - 2048x2048(full)
Binning 1x1(No Binning)
Pixel Output: 2048 x 2048



3.4.4 Gain Settings

3.4.4 (a) Gain

The Gain Settings control box, shown in Figure , allows you to change the Gain value from 2.97dB to 21.96 dB. To change the value, move the slider or enter the value directly into the text box.

_ Gain	i Settings ———				
A(dB)) 2.97	21.96			
9.99	- i jr				
B(dB)	2.97	21.96			
9.99	- i				
(Note:At auto balancing, channel B aligns to channel A)					
Auto CH Balancing					

Gain Channel Balance Control 3.4.4 (b)


Click the "Channel Balance" button to enable gain channel balancing. Once gain channel balancing has finished, the software disables this feature automatically. Please note that when channel balancing, channel B aligns to channel A. Good channel balance is obtained by exposing the camera to a uniform light source under 80% saturation. If the camera is in Async trigger mode and the trigger frequency is low (or slow), it may take longer to collect enough frames to balance the channel. Another condition in which Channel Balance may not work properly is when you use the high-speed shutter under lowfrequency light, such as fluorescent light. In both cases, the channel balance will time-out in 10 seconds if the balance is not reached.

3.4.5 The Gain

Offset Level

The Channel A offset level is master, the channel B is slave. The offset level box, shown in Figure 17, allows you to change Channel A offset voltage. To change the value, move the slider or enter the value directly into the box. The camera itself automatically adjusts Channel B offset voltage, every other frame. Please note that offset level control is not available in scan modes C and D.

FIGURE 17. Offset Level






3.4.6 Look-Up Table

The look-up table (LUT) control, shown in Figure 18, allows you to change two knee point values.





Enter X_1 , Y_1 , X_2 , Y_2 values directly to adjust the knee curve. In the integrated camera software, the look-up table can also be controlled interactively. The Table Selection pull-down menu allows you to select the Linear or Gamma 45 option. This control also allows you to check the positive or negative box to choose an image option.

3.4.7 Memory Pages

All the camera parameters such as shutter mode, shutter speed, gain, offset level, scan mode, and LUT can be saved into seven available memory pages on the EEPROM in the camera. The pages are numbered 0-6. The Load Page button loads the corresponding camera settings from the EEPROM while the write page button writes the current camera settings to the corresponding memory page in the EEPROM.

Page 1, shown in Figure 19, is the power-up default page. Page 0 is the factory default. To save your current camera settings for power up default, write the settings to memory page 1.

FIGURE 19. Memory Pages

	1x1(No Binning) Pixel Output: 640 x 480						
	Memory Pages						
	Load Page						

To reset memory page 1 to the factory default settings, load memory page 0 and save those settings to memory page 1. Page 0 is password-protected and you cannot write to it. If you find that you do need to write to page 0, contact JAI PULNIX for password access.



Note: Configurations such as grabber settings, pulse generator, GPIO, and image setting must be saved into the XML file. Refer to Section 3.4.1, "Check the Current Camera Setting," on page 12 for more information.

3.4.8 Free-Running Mode

The camera must be in "Manual Shutter" or "Direct Shutter" mode. In the example below, there is no partial scan.

- 1. Connect to the camera.
- 2. Under the "Device Features" tab, set the GPIO look-up table to Q5=1.
- 3. Under the "GigE Software" tab, change the manual shutter or direct shutter values.
- 4. Click Start.

You should now see a free-running video stream.

3.4.9 Externally Triggered

The external trigger is sent through pin 6 of the 12-pin Hirose connector. To use the software to enable the external trigger, use the following steps:

- 1. Change the GigE camera software shutter mode to Async. Shutter.
- 2. Set the GPIO look-up table to Q4 = I0 and Q5 = 1.

3.4.10 Internally Triggered

The camera-control software includes pulse generators that you can use to trigger the camera internally. To do this, use the following steps:

- 1. Select "Pulse Generator 0" under the "Device Features" tab. Set the pulse width and delay and check the "Periodic" option if needed.
- 2. Set the GPIO look-up table to Q5=1 and Q4=I7.
- 3. Set the shutter mode in the GigE camera software page to async shutter. For more information, refer to Section 3.4.2, "Exposure Control," on page 13.

3.4.11 Save/Restore Settings to Your Hard Disk

To save your current settings into the XML file, go to the main menu, select "File" and click on **Save As**. The XML file saves all your configurations such as grabber settings, pulse generator, GPIO and language settings.

The XML file will not, however, save camera parameters such as shutter mode, shutter speed, gain settings, offset level, scan mode, and LUT. For more information about saving these camera parameters, please refer to Section 3.4.7, "Memory Pages," on page 16.

3.4.12 White Balance Control (Color Versions Only)

To determine white balance, use the following steps:

- 1. Select scan mode A and no binning in the GigE Camera Software tabbed dialog. shown in Figure 11 on page 11.
- 2. Start the live video by clicking **Start** in the Acquisition tab of the Camera Interface Application dialog box.
- **3.** Select "Color Adjustment" under tools in the main menu. Show the camera a piece of white paper to make sure that the image is not saturated.
- 4. Click Analyze to automatically calculate the white balance.
- 5. Once white balance has been calculated, click **Apply Results** to apply white balance. You can also assign custom gain and offset values to the R, G, and B channels. If you choose to assign custom values, click **Apply Results**.

FIGURE 20. White Balance Control Settings.

	Configurati	Configuration - Advanced						
Custom white balance. Gain/Offset Automatic white (Image 1 Device F Gains & D Red Green Blue White Ba Analy	Settings Features Uffsets Gains 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Pixel Type Port Communication Offsets 0 0 0 0	Grabber Settings RGB Filter Apply Reset	Grabber Features GigE Camera Software			
balance. Gain/Offset	White Ba	ze		le)				

3.4.13 Main Menu: "Option"

3.4.13 (a) Test Pattern

The Grabber Settings tabbed dialog box has a check box to enable the test pattern that is internally generated by the integrated camera software.

3.4.14 Version

View the version number of the Cam2Net camera interface application by clicking on **Help-->** About. The version number of the integrated GigE camera software is seen in a text box control called "Version" in the GigE Camera tabbed dialog box.

3.4.15 Exit

From the main menu, select "File," and click "Exit" to exit the software.

TM-4100GE Software **PULDIX**®

4 Signal Handling

This section briefly describes the signal handling of the GE cameras in the following sections:

- "Camera Inputs" on page 19
- "GPIO Control Block" on page 20
- "GPIO Look-Up Table" on page 22
- "GPIO Label Tables" on page 22
- "Pulse Generators" on page 24

Refer to the Cam2Net User's Manual for additional details.

4.1 Camera Inputs

For information on the polarity and type of the signals required to support specific camera functions, refer to "Asynchronous Reset" on page 39.

The TM4100GE has four externally controllable standard signals:

- Trigger (VINIT or EXT_TRIG) (CC1 equivalent)
- Integration Control (INTEG/ROI) (CC2 equivalent)
- VD in (EXT_VD) (CC3 equivalent)
- HD in (EXT_HD) (CC4 equivalent)

The labels for these signals in the GPIO Control Block programming language are:

- I0, for VINIT (must be configured as EXT_TRIG)
- I1, for VD in (must be configured as EXT_VD)
- I2, for HD in (must be configured as EXT_HD)
- I4, for Integration control (must be configured as INT)

For normal exposure operation, the INTEG signal must be high. In the GPIO lookup table language: Q5=1. When it is low, the CCD readout is inhibited. To use the Integration Control, set Q5=I3 in the GPIO lookup table.

4.2 Camera Outputs

When the Asynchronous Trigger is used, the strobe output indicates the exposure period.


• I-4 for strobe output (must be configured as CAM_STROBE)



4.3 GPIO Control Block

Figure 21 below shows the GPIO Control Block signals for the GE Cameras.

FIGURE 21. GE Camera GPIO Control Block



Inputs I0 through I7 can be either external or internal inputs to the look-up table. The outputs are used by the imager part of the GE camera.

The HD and VD signals can be passed through, bypassing the GPIO lookup table. Figure 23 on page 22 shows a screen dump of the GPIO function select page, where HD/VD bypass selection can be made. The default value 0 (zero) is through the lookup table. Value 1 (one) is bypassing the lookup table.

The SDK and the Cam2Net Camera Interface Application both supply methods to select GPIO bypass of the external VD and HD (I1 and I2).

It is also possible to select which signal source to lead to the GPIO inputs. This is done in the GPIO look-up table page as shown in Figure 22.

FIGURE 22. GPIO Look-Up Table

Cor	figuration - Advance	ed	×	
	Image Settings Device Features	Pixel Type Grabber Settings Grabber Features Port Communication RGB Filter GigE Camera Software		
+	Pulse Generator 1		^	
+	Pulse Generator 2			
+	Pulse Generator 3			
+	Counter 0			
	GPIO Look-Up Table		=	
	Input 0 Configuration TTL Input 0			
	Input 1 Configuration	TTL Input 1		
	Input 2 Configuration	GPIO Control Bit 3		
	Input 3 Configuration	GPIO Control Bit 2		
	Input 4 Configuration	GPIO Control Bit 1		
	Input 5 Configuration	GPIO Control Bit 0		
	Input 6 Configuration Pulse Generator 1 Output			
	Input 7 Configuration	Pulse Generator 0 Output		
	LUT Program	Q4 = I0 Q5 = 1 Q0 = I4		

FIGURE 23. The GPIO Configuration

Configuration - Advanced					
F	Image Settings	Pixel Type	Grabber Settings RGB Filter	Grabber Features GigE Camera Software	
+	Input Debouncing				
	GPIO Configuration				
	Input 0 Configuration	0			
	Input 1 Configuration	0			
	Input 2 Configuration	0			
	Input 3 Configuration	0			
	Output 0 Configuration	0			



4.4 GPIO Label Table

Table 2 shows which GPIO inputs carry the different signals. The top line for each label contains the default signal.

Input Label	Signal	Description
10	TTL_IN(EXT_TRIG)	TTL-input 0. Used for external trigger.
10	FDV	Internal signal. Frame Data Valid.
11	TTL_IN(EXT_VD)	TTL-input 1. Used for external vertical drive.
11	LDV	Internal signal. Line Data Valid.
12	CTRL2	Internal control signal.
12	TTL_IN(EXT_HD)	TTL-input 2. Used for external horizontal drive.
13	CTRL1	Internal control signal.
15	TTL_IN(INT)	TTL-input 3. Used for external integration control.
I4	CAM_STROBE	Internal signal. Strobe Input.
14	PULSE_GEN3	Pulse Generator 3 signals go here.
15	CTRL0	Internal control signal.
15	PULSE_GEN2	Pulse Generator 2 signals go here.
16	PULSE_GEN1	Pulse Generator 1 signals go here.
10	N/A	
17	PULSE_GEN0	Pulse Generator 0 signals go here.
1/	N/A	

TABLE 2. GPIO Look-Up Table Input Labels

Page 24 Signal Handling

Table 3 shows which output labels carry the output signals.

TABLE 3.GPIO	Look-Up Table Output La	bels	
Output label	Signal		Desci
00	TTL-OUT(STROBE)	Strobe output	

Output label	Signal	Description	
Q0	TTL-OUT(STROBE)	Strobe output	
Q1	N/A		
Q2	N/A		
Q3	N/A		
Q4	EVINIT	Trigger	
Q5	INTG_CON	Integration control	
Q6	EXT_VD	Vertical Drive	
Q7	EXT_HD	Horizontal Drive	
Q8	pulse_trig1	Pulse Generator 1 gets its trigger here	
Q9	pulse_trig0	Pulse Generator 0 gets its trigger here	
Q10	pulse_trig3	Pulse Generator 3 gets its trigger here	
Q11	pulse_trig2	Pulse Generator 2 gets its trigger here	
Q12	N/A		
Q13	N/A		
Q14	TRIG	Trigger for camera's internal frame grabber	
Q15	RESV	Reserved	



4.5 Pulse Generators

The TM-4100GE camera has four independently programmable pulse generators. These generators can run as either periodic or triggered. To run the pulse generators as triggered, they can be triggered on either levels or signal edges. These generators can be tied to the camera inputs (camera-control lines). For example, you can set pulse generator 0 in the Device Features tabbed dialog box to the following values:

Delay = 600

Width = 14,000

Granularity = 1

Now check the Periodic option and change the camera settings to Async 9. This triggers the camera, based on the pulse width set in the Pulse Generator page.

Be careful with the pulse generator's GPIO input and output polarity. If the delay and pulse-width duration are switched around, the output polarity must be negated in the GPIO lookup table.

The pulse generators are configured in the "Pulse Generator" section of the "Device Features" tab of the Advanced Configuration window as shown in Figure 24.

FIGURE 24. Pulse Generator Page

Configuration - Advanced					×
F	Image Settings Device Features	Pixel Type	Grabber Settings RGB Filter	Grabber Features GigE Camera Software	
	Flow Control				^
	Inter Packet Delay	0			
	Inter Packet Delay (ns)	0			
	Expected Data Rate (10000000			
	Link Speed	1000 MBits/seconds			
	Resulting Inter-Packe	0			
	Pulse Generator 0				
	Width	4096			
	Delay	1024			
	Granularity	0			
	Periodic	FALSE			
	Trigger Mode	Triggered on rising e	dge		
	Pulse Period (ns)	153630			
	Pulse Frequency (Hz)	6509.145349			
+	Pulse Generator 1				
+	Pulse Generator 2				
+	Pulse Generator 3				~

5 GigE Series Camera Serial Commands

You can control the GigE series cameras by serial command either using RS-232 or Camera Link. The Start character is always ":" and the End character is always <CR> (return). For example, to set Asynchronous Pulse Width Mode, send the command :ASH=9<CR> to the camera. Table 4 lists serial commands that can be used to control the camera.

Command	Parameters	End of Command	Ack Response	Description		
	Gain Control					
:MGA=	DDD	<cr></cr>	:0 <cr></cr>	Set CDS gain for ch A (DDD = $042 \sim 1E8$)		
:MGB=	DDD	<cr></cr>	:0 <cr></cr>	Set CDS gain for ch B (DDD = $042 \sim 1E8$)		
:MGA?		<cr>></cr>	:oGA[DDD] <cr></cr>	Enquire CDS gain for ch A		
:MGB?		< <u>cr</u> >	:oGB[DDD] <cr></cr>	Enquire CDS gain for ch B		
:EABL		<cr>></cr>	:0 <cr></cr>	Enable auto gain balance		
:DABL		<cr>></cr>	:0 <cr></cr>	Disable auto gain balance		
:ABL?		<cr></cr>	:oAB[N] <cr></cr>	Check if auto gain balance is enable ($N = 1$ Enable, $N = 0$: Disable)		
	ADC Reference Voltage Control					
:VRA=	DDD	<cr></cr>	:0 <cr></cr>	Set reference voltage for ch A (XXX = 000 ~ 1 FF)		
:VRB=	DDD	<cr>></cr>	:0 <cr></cr>	Set reference voltage for ch B (XXX = 000 ~ 1 FF)		
:VRA?		<cr>></cr>	:oVA[DDD] <cr></cr>	Enquire reference voltage for ch A		
:VRB?		<cr>></cr>	:oVB[DDD] <cr></cr>	Enquire reference voltage for ch B		
Shutter Control						
:MSH=	S	< <u>cr</u> >	:0 <cr></cr>	Set Manual shutter (S = $0 \sim 9$)		
:DSH=	DDD	<cr></cr>	:0 <cr></cr>	Set Direct shutter (DDD = $000 \sim XXX^*$)		
:ASH=	S	<cr></cr>	:0 <cr></cr>	Set Async shutter (S = $0 \sim 9$)		
:ADS=	DDD	<cr></cr>	:0 <cr></cr>	Set Async Direct Shutter (DDD=000-81F)		
:SHR?		<cr></cr>	:o[shtr] <cr></cr>	Enquire current shutter mode and number		

TABLE 4. TM-4100GE Command List



Command	Parameters	End of Command	Ack Response	Description
			Lookup Table	
:GM45		< <u>cr</u> >	:0 <cr></cr>	Set gamma (.45) table
:LINR		<cr></cr>	:0 <cr></cr>	Set linear table
:KNEE=	X1Y1X2Y2	<cr></cr>	:0 <cr></cr>	Set knees (X1, Y1, X2, Y2 = $00 \sim FF$)
:SLUT	N	<cr>></cr>	:0 <cr></cr>	Set positive knee or negative knee (N = 0 : positive, M = 1 : negative)
:LUT?		< <u>cr</u> >	:o[lut] <cr></cr>	Enquire current LUT setting
			Memory Pages	
:WRPG	N	< <u>cr</u> >	:0 <cr></cr>	Write Page N (N = $0 \sim 6$; Page 0 is factory setting and not allowed to change by customer)
:LDPG	N	<cr></cr>	:o[settings] <cr></cr>	Load Page N (N = $0 \sim 6$)
:RDPG	Ν	<cr></cr>	:o[settings] <cr></cr>	Read (Report) Page N (N = $0 \sim 6$)
			Scan Mode	
:SMD	М	<cr>></cr>	:0 <cr></cr>	Set Mode $(M = A, B, C, D)$
:SMD?		<cr>></cr>	:oMD[mode] <cr></cr>	Enquire current scan mode
			Miscellaneous	
:RPST		< <u>cr</u> >	:o[settings] <cr></cr>	Report Current Overall Settings
:TPTN	N	<cr>></cr>	:0 <cr></cr>	Enable/Disable Test Pattern (N = 1 : Enable, N = 0 : Disable)
:CAM?		< <u>cr</u> >	[CamMode]	Enquire Camera Model
:VER?		<cr></cr>	[version]	Enquire current version of firmware

TABLE 4. TM-4100GE Command List (Continued)

*. Maximum size is equal to the maximum line number of each scan mode.

Note: If a command is not accepted for any reason, the camera will return a Nack response ":e" < cr >

Report Command: RPST<cr>

TS Return : O RR + "24 bytes" + < cr >

TM-4100GE Software **PULNIX**®

TABLE 5.18 Bytes Status Report

Byte 1, 2	MGA		Channel A Gain Control (H'042 - H'1E8)
Byte 3, 4	VRA		Channel A Offset Voltage (H'000 - H'1FF)
Byte 5, 6	MGB		Channel B Gain Control (H'042 - H'1E8)
Byte 7, 8	VRB		Channel B Offset Voltage (H'000 - H'1FF)
Byte 9	Function Flag 0		
	Bit 7	output pixel order 1	"00"=< "10"=<
	Bit 6	output pixel order 0	
	Bit 5		
	Bit 4		
	Bit 3		
	Bit 2		
	Bit 1 Bit 0		"00" = Scan area A "01"=Scan area B "10"=Scan area C "11"=Scan area D
Byte 10	Function Flag 1		
	Bit 7	ShutterMode2	"000"=Manual Shutter
	Bit 6	ShutterMode1	"001"=Async Shutter
	Bit 5	ShutterMode0	"011"=Direct Shutter
	Bit 4	Output Data Depth 0=8 bit	0=8bit; 1=10bit
	Bit 3	ShutterSpeed3	
	Bit 2	ShutterSpeed2	
	Bit 1	ShutterSpeed1	- "0000" - "1001" Shutter Speed 0 - 9
	Bit 0	ShutterSpeed0	-
Byte 11	Function Flag 2		
	Bit 7	LUTSIGN	0=Positive LUT; 1=Negative LUT
	Bit 6		
	Bit 5		
	Bit 4		
	Bit 3		
	Bit 2	LUTTABLE2	"000"=Linear LUT
	Bit 1	LUTTABLE1	"001"=Gamma.45 LUT
	Bit 0	LUTTABLE0	"010"=Two Knee Table



Byte 12	Function Flag 3		
	Bit 7	TESTPATTERN	0=Disable TP; 1=Enable TP
	Bit 6	PASSWORD	0=Disable PW; 1=Enable PW
	Bit 5		
	Bit 4		
	Bit 3		
	Bit 2		
	Bit 1		
	Bit 0	AUTOBALANCING	0=Disable AB; 1=Enable AB
Byte 13	X1		(X1, Y1) Coordinate for Knee 1
Byte 14	Y1		(X1, Y1 = H'00 - H'FF)
Byte 15	X2		(X2, Y2) Coordinate for Knee 1
Byte 16	Y2		(X2, Y2 = H'00 - H'FF)
Byte 17	Reserved		
Byte 18	Reserved		
Byte 19	Reserved		
Byte 20	Reserved		
Byte 21, 22	Direct Shutter		H'000 - H'81F
Byte 23, 24	Reserved	Total line number	H'040 - H'1F3

TABLE 5. 18 Bytes Status Report (Continued)

Page 30 GigE Series Camera Serial Commands



TM-4100GE Hardware

Operation Manual



6 Hardware Introduction

6.1 Product Description

The JAI PULNIX TM-4100GE series¹ is a Gigabit Ethernet output, high-resolution progressive scan CCD camera. The interline-type CCD permits full vertical and horizontal resolution of very high speed shutter images and applications. The electronic shutter, which has speeds to 1/16,000 sec., can be reset asynchronously by external pulse control. The frame rate for a full image is 15 fps. A square imager format with uniform square pixels provides superior image definition in any orientation. On-chip micro lenses provide increased sensitivity.

The TM-4100 GE^2 has a full dynamic range control function, which can be set at externally selectable look-up table (LUT) knee slopes to convert 10-bit input to 8-bit output, thereby optimizing the CCD's full dynamic range in the normal output signal range. As a Gigabit Ethernet output camera, the TM-4100GE has semi-auto-gain balancing functions.

Applications for the TM-4100GE include machine vision, medical imaging, intelligent transportation systems, high-definition graphics, on-line inspection, gauging, character reading, archiving, and highsecurity surveillance.



^{1.} Unless otherwise stated, all information in this manual applies to both cameras in the TM-4100GE series, the TM-4100GE and the TMC-4100GE.

^{2.} The TM-4100GE is available with either 8-bit processing or 10-bit processing. You must specify your choice of configurations when you purchase the camera.

6.2 Features

• Miniature size and light weight

The printed circuit boards in the TM-4100GE have been arranged to create modular electronics, giving the camera flexibility. In addition, the use of miniature solid-state components results in a compact, lightweight camera that is 50.8mm x 50.8mm x 81.5mm in dimensions, and weighs only 155 grams.

• Imager

The TM-4100GE uses a dual-tap progressive scan interline transfer CCD that has the following features:

- Resolution of 2k x 2k active pixels for excellent image quality.
- 7.4 x 7.4 µm square pixels for precise dimensional measurement.
- High-speed electronic shutter capability for high dynamic resolution of moving objects that eliminates the need for a mechanical shutter.
- Progressive scan CCD eliminates interlace deterioration of image and increases ease of computer interface.
- High sensitivity and low noise at fast scanning. The CCD has an excellent S/N ratio at the default setting that is greater than 48dB.
- The CCD has a built-in microlens for increased quantum efficiency.

• Electronic shutter

The TM-4100GE has a substrate drain-type shutter mechanism which provides superb pictures at various speeds without smearing. For more information, please see Section 8.3, "Electronic Shutter," on page 44.

Asynchronous reset

The TM-4100GE captures async reset images and provides single-shot video output with single FDV. This makes it simpler for an ordinary frame grabber to capture the asynchronous reset images. The TM-4100GE's asynchronous reset is flexible and accepts external horizontal drive (HD) for phase locking. When the VINIT (5V) pulse is applied to CC1, it resets the camera's scanning and purging of the CCD.

The TM-4100GE has three modes to control the asynchronous reset and shutter speed:

- Async, no shutter. The video signal and FDV are reset by external VINIT.
- Internal shutter speed control. The speed control varies from 1/60 to 1/16,000 sec. The video signal and FDV starts with internal V reset timing related to shutter speed.
- External VINIT with pulse width. The duration between pulse edges controls the shutter speed externally.



• Output

The TM-4100GE has a dual-tap 10-bit/8-bit Gigabit Ethernet output.

• Dual-channel auto black level balancing and semi-auto gain balancing

The TM-4100GE, as a dual-tap output camera, has auto black level balancing and semi-auto gain balancing functions.

• Integration

The TM-4100GE is capable of capturing high-resolution integration images. Its CCD imager can be exposed for longer than the normal scan timing of 1/15 sec. This integration feature provides extra sensitivity for applications in dark environments. The progressive scan imager permits a full frame of resolution in non-interlace format. Integration is achieved by applying INTEG signal to CC2 control of Gigabit Ethernet or by feeding VINIT pulse width control up to 1 sec of the pulse width in async pulse width control mode for the frames to be integrated.

• Warranty

Please contact your factory representative for details about the warranty.

7 Installation

The following instructions are provided to help you to set up your camera quickly and easily. We suggest that you read through these instructions before you unpack and set up your camera system.

7.1 Getting Started

7.1.1 Unpacking Instructions

We recommend that you save the original packing cartons for the cameras and accessories in case you need to return or exchange an item.

We also recommend that you bench-test any equipment being sent to another location for field installation to assure that everything is fully operational as a system.

7.1.2 Components

When you receive your TM-4100GE camera from JAI PULNiX, the contents of the shipping box should include the camera and a document download card. If either of these items are missing, please contact your JAI PULNiX representative immediately. The document download card includes instructions and web locations for downloading the datasheet, manual, and camera-control software. If you do not have Internet access, please contact JAI PULNiX to receive this material on a CD-ROM.

7.1.3 Accessories and Options

Following is a list of additional accessories and options that may be required for your application. Please check with your JAI PULNiX representative before you install your camera to determine what you might need.

- PD-12U series power supply
- 12P-02S power cable
- Cat5e or cat6 shielded Ethernet cable (not supplied by JAI PULNiX)



7.2 Camera Setup

7.2.1 **Heat Dissipation**

The TM-4100GE is a compact 2k by 2k camera. Since all the electronics have been packed in a compact package, the outer case of the camera can become hot due to heat dissipation. For optimal performance, JAI PULNiX recommends using a cooling fan to set up a positive air flow around the camera and following the precautions below.

- Mount the camera on a large heat sink (camera bracket) made out of heat-conductive material like • aluminum.
- Make sure the flow of heat from the camera case to the bracket is not blocked by a non-conductive • material like plastic.
- Make sure the camera has enough open space around it to facilitate the free flow of air. •


Please contact JAI PULNiX, Inc. at (800) 445-5444 or send an E-mail to imaging@jaipulnix.com if you have any questions.

7.2.2 Connector Pin Configurations

7.2.2 (a) 12-Pin Connector

The TM-1327GE has a 12-pin Hirose connector for power input and signal integration as shown in Figure 24.

Figure 24. 12-Pin Connector Pinouts



Pin #1 is Ground and pin #2 is +12V DC. Table 6 shows the pin-out table.

Pin	Description	Pin	Description
1	GND	7	VD in
2	+12V DC	8	Strobe
3	GND (analog)	9	HD in
4	Reserved	10	Reserved
5	GND (digital)	11	Reserved
6	VINIT in	12	Reserved

Table 6. **12-Pin Connector**



7.2.2 (b) Ethernet Connector

The GigE socket, marked on the camera's back panel as "GigE," is a standard RJ-45 Ethernet socket as shown in Figure 25.

Figure 25. GigE Ethernet Connector



Use at least cat5e UTP cables (cat6 cables are preferred). Refer to the *Cam2Net User's Manual* for details. JAI PULNIX recommends the use of shielded cables to reduce emissions and for CE/FCC compliance. Double-shielded cables further reduce emissions.

7.2.3 Power Supplies and Power Cable Setup

7.2.3 (a) Power Supplies

The TM-4100GE camera requires 12V DC power that is obtained through the 12-pin connector located on the rear panel of the camera. JAI PULNiX recommends the following power supplies:

PD-12UU	100-240V AC/12V DC	1.2A universal voltage power supply, US Plug
PD-12UUP	PD-12UU with12-pin connector	US plug
PD-12UE	PD-12UU	European plug
PD-12UEP	PD-12UU with 12-pin connector	European plug

For users providing power through the 12-pin connector, the PD-12P, PD-12UEP and PD-12UUP power supplies are available with the 12-pin mating connector already attached to the leads from the power supply. The PD-12UU and PD-12UE power supplies can be connected to the JAI PULNiX power cable either directly or using a terminal strip.


When wiring the PD-12UU and PD-12UE power supplies directly, please note the following:

- The lead ends must be twisted together and tin-soldered for strength and electrical continuity.
- Shrink tubing or a similar insulator should be used to prevent exposed leads from touching and shorting.
- The +12V lead is marked with a red stripe or white lettering; be sure not to reverse the leads.
- All connections must be properly insulated to prevent shorting.

7.2.3 (b) JAI PULNiX Power Cables

If you are using JAI PULNiX power cables such as the 12P-02S, please refer to the 12-pin connector pin-out diagram below. The cable pin-out diagram is shown in Figure 26. The color-coded leads use Gray for Ground and Yellow for +12V.

FIGURE 26. 12P-02S Interface Cable (optional)



	12P-02S Interface Cable				
Pin#	Lead Color	Function	Pin#	Lead Color	Function
1	Gray	GND	7	Black coax	TTL IN (EXT_VD)
2	Yellow	+12V DC	8	White coax shield	TTL OUT (STROBE)
3	Red coax shield	AGND	9	White coax	TTL IN (EXT_HD)
4	Red coax	RESV	10	Brown	RESV
5	Orange coax shield	GND	11	Blue	TTL IN (INTG_CON)
6	Orange coax	TTL IN (EXT_TRIG)	12	Black coax shield	RESV

Note: Make sure that the unused leads are not touching and that there is no possibility that exposed wires could cause the leads to short.

7.2.3 (c) Building Your Own Power Cable

Refer to the 12-pin connector pin-out in Figure 24 on page 35. Connect the Ground lead to pin #1, and the +12V DC lead to pin #2 of the 12-pin connector. Power must be DC-regulated, and of sufficient current to properly power the camera.

7.2.3 (d) Attaching the Power Cable to the Connector

The 12-pin connector is keyed and will only fit in one orientation. Follow these directions to properly attach the power cable to the camera connector:

- 1. Rotate the connector while applying slight pressure until the keyways line up.
- 2. Press the connector into place until firmly seated.
- 3. Plug the power cord into the 100V AC socket. This powers-up the camera.

7.2.4 Attaching the Camera Lens

The TM-4100GE camera accepts 1.2" or larger format size C-mount lenses. To attach the C-mount lens¹ to the camera, carefully engage the threads and rotate the lens clockwise until it firmly seats on the mounting ring. Do not force the lens if it does not seat properly. Please note that some lenses with extremely long flangebacks may exceed the mounting depth of the camera.

7.2.5 Adjustable Back-Focus

Before cameras are shipped, back focus is carefully set using a collimator, oscilliscope and other specialized equipment. While the factory-set focus serves well in most cases, an adjustable back focus makes it possible to improve image sharpness when using lower-cost zoom lenses, custom optics, or in unusual parameters.

There should be an obvious need to refocus the lens before attempting to change the back focus. This is a very exacting task. Some cameras have been returned to the factory to reset the back focus after failed attempts to change the focus by customers. It might be wise to label cameras whose back focus was adjusted

- 1. The camera must be connected to a monitor before attempting to adjust the back focus.
- 2. To back focus the camera, first attach a C-mount lens in the mount. Be certain that the lens is properly seated.
- **3.** Next set the lens focus to infinity (if the lens is a manual iris, set the iris to a high f number while still retaining a well illuminated image).
- 4. Loosen the three miniature hex set-screws (use a 0.9 mm hex wrench) that lock the focus ring in place (two screws for a CS-mount). Slowly turn the lens and focus ring assembly back and forth until you obtain the best image of the desired object. This sets the back focus. Once the best image is obtained, tighten the focus ring set-screws until they are snug. Do not over-tighten the screws.

Note: Mini-bayonet cameras adapted to C-mount do not have the back focus feature.

^{1.} C-mount to F-mount and C-mount to K-mount adapters are available for larger format lenses (35mm). Check with local photography dealers for these lens adapters.

FIGURE 27. Back-Focus Set-Screw Locations



Loosen the three 2mm screws around the perimeter of the C-mount lens collar (two 2mm screws for a CS-mount) to adjust the back focus. Unless you absolutely must, do not attempt to adjust this focus.



8 Operation

8.1 Progressive Scanning

Standard TV-system scanning is 525 lines interlace scanning as specified in the RS-170 protocol. Every other horizontal line (odd lines and even lines) is scanned at a 60Hz rate per field, and the scanning is completed with two fields (one frame) at 30Hz rate. Because of the interlace scanning, the vertical resolution of CCD cameras is limited at 350 TV lines, regardless of the horizontal resolution. When electronic shutter is applied, the CCD can hold only one field of charge at each exposure. This means that the vertical resolution of the electronic shutter camera is only 244 TV lines. The situation is the same for an HDTV-format camera, since it has interlaced scanning and the vertical resolution of the shuttered image is 500 lines.

The TM-4100GE uses a state-of-the-art progressive scanning interline transfer CCD which scans all lines sequentially from top to bottom at one frame rate. Like a non-interlace computer screen, it generates a stable, crisp image without alternating lines and provides full vertical TV resolution of 2048 lines (a normal computer monitor has a maximum display of 1600 lines).

The interline transfer architecture is also important to generate simultaneous shuttering. This is different from full frame transfer architecture, which requires a mechanical shutter or strobe light in order to freeze the object motion.

The TM-4100GE outputs the progressive scanned image with an electronic shutter in two different formats. See Table 8 on page 45 for more information.


1. Progressive scanning digital output

The CCD signal goes through A/D converters 10-bit in, 10-bit/8-bit out. The digital output is available using the Gigabit Ethernet connector.

2. Full Progressive Scan

Normal scanning mode for the TM-4100GE is 2k x 2k pixels. The standard speed with dual-channel output is 15 frame/sec at the pixel clock of 40 MHz. The progressive scan reads every line from top to bottom and all lines are exposed with a single electronic shutter.

FIGURE 28. Full Progressive Scan Mode (A)





3. Partial Scan Mode

By selection, the camera has three partial scan modes: centered 1000 lines, centered 500 lines, and 250 lines. Partial scan mode 1000 lines. Partial scan's frame rate is 28 fps, 500 lines is 50 fps, 250 lines is 80 fps.

Scan Area	Active Area	Vertical Frequency (Hz)	Horizontal Frequency (kHz)	Output Data Clock (MHz)
А	2048 x 2048	14.79		
В	2048 x 1000	27.7	30.77	40
С	2048 x 500	49.63	50.77	40
D	2048 x 250	79.92	Ì	

8.2 Bayer Color Filter (Color Versions)

JAI PULNiX AccuPiXEL series color cameras are high-resolution, high-speed progressive scan CCD cameras. The interline transfer, progressive scan CCD permits full vertical and horizontal resolution of images acquired at very high shutter speeds. The electronic shutter, which has speeds to 1/16,000 sec., can be reset asynchronously by external pulse control. Uniform square pixels provide superior image definition in any orientation. On-chip micro lenses mean increased sensitivity.

8.2.1 Color Filter Array

JAI PULNiX AccuPiXEL cameras use Bayer CFA (color filter array) as their standard primary color filter. This filter provides the most popular color interpolation supported by numerous software suppliers.

The digital format allows the camera to output accurate pixel data, including the color information. When the data is stored in the frame buffer of a frame grabber or computer, the color information is easily manipulated to restore the original color images. Because the color filter array contains only a single R, G or B color in each pixel, the restored image has to fill in colors in the missing pixel locations. The software uses neighboring pixel information to "guess" the missing colors to make smooth, clear images. This is called "color interpolation." Today's high-speed computers allow such color interpolation to be done almost in real time. Because these cameras do not contain internal color-processing circuitry, they are smaller and less expensive than full-function color cameras.


8.2.2 Bayer Color Filter Array (CFA)

The Bayer CFA is an R, G, B primary color filter array. This is the most widely accepted CFA for the single-chip CCD progressive scan format. This type of array layout has a specific order for each color's pixels. Since the human eye's resolution and color recognition are highest at green, the CFA contains two greens per each red and blue.

It is critical for the frame grabber and color interpolation to know where the individual color pixels exist relative to sync (LDV and FDV) timing.

TM-4100GE Hardware **PULDIX**

This requirement makes digital output the preferred choice, because the timing relationships are very accurate






8.2.3 Starting Pixel Configuration

All manufacturers produce identical Bayer CFAs, but there are slight differences between the CCDs produced by different manufacturers. The first line is generally R and G. The camera timing can be adjusted to start with either G or R by skipping the very first pixels at each lines. The majority of color interpolation software can select between a variety of pixel relations, such as R/G start or G/R start, as well as G/B start and B/G start. Once the correct scanning is configured, the rest of the interpolation will be exactly the same. Please contact JAI PULNiX for further information regarding CCD manufacturers.







8.2.4 Sync and Data

The individual color data is exactly the same as the pixel data. This means that the timing relationships of the color cameras are also the same as of the B/W cameras.

For a detailed timing chart, please refer to each B/W camera's data sheet and manual.

The following diagram is an example of the TMC-4100GE default mode. FDV and LDV are used internally for the GigE interface.




FIGURE 31. Example of TMC-4100GE (Same as TM-4100GE)

8.2.5 Camera Functions

AccuPiXEL color cameras perform all functions the same way as B/W cameras. However, because of color characteristics, the LUT (Look-up Table) is different. The LUT is a powerful tool to adjust the dynamic range as well as color dynamic range. Since human color perception is non-linear, LUT

TM-4100GE Hardware **PULDIX**®

selection can help optimize color contrast by selecting the LUT value. Gamma 0.45 is logarithmic and is closed to human perception.

When LUT is selected, black-level adjustment must be more accurate than for B/W cameras.

For a detailed timing chart, please refer to the standard AccuPiXEL camera data sheet, or contact JAI PULNiX.

8.2.6 Interpolation Software

The color interpolation can be performed in the frame grabber or by using the host computer's CPU. Most major frame grabbers with processing capability provide tools for color interpolation. Software vision packages also provide color interpolation capability, but speed and performance may be determined by the PC's resources and by the complexity of the interpolation routine.

8.2.7 Color Interpolation

The Bayer pattern color filter array (CFA) consists of R, G, and B primary colors. Each pixel represents one of three colors. In order to display or print color images, the signal has to be converted to RGB output, which has three independent channels (outputs) and sync signals.

Color interpolation software or firmware performs the color preprocessing by filling the missing color pixels with neighboring pixels. It then separates the stream of data, (8-bit or 10-bit) into 3 (RGB) data (8-bit x 3) and adds the color matrix to adjust and balance each of the R,G, and B channels (white balance or color balance).

Green	Red	Green
Blue	Green	Blue
Green	Red	Green

The image quality depends on the camera's own pixel data (including pixel data independency from neighboring pixels, noise and color filter), and interpolation of the software algorithm such as 3×3 interpolation, 2×2 interpolation, color matrix, white balance capability, and so on.

All AccuPiXEL color cameras are carefully designed for maximum color performance. JAI PULNiX strongly suggests that you use digital output for the best performance.

Some software is used on board (FPGA or DSP) to perform the interpolation. Other software simply uses the host computer's memory and CPU. The process speed may vary depending on the architecture and speed of the computer.

8.3 Electronic Shutter

The TM-4100GE has a substrate drain-type shutter mechanism which provides a superb picture at various speeds without smearing. A built-in fixed shutter speed control selects the electronic shutter rate.

Shutter Speed Number	Manual	Async.
0	1/frame rate	Async No Shutter
1	1/60 sec	1/16,000 sec
2	1/125 sec	1/8,000 sec
3	1/250 sec	1/4,000 sec
4	1/500 sec	1/2,000 sec
5	1/1,000 sec	1/1,000 sec
6	1/2,000 sec	1/500 sec
7	1/4,000 sec	1/250 sec
8	1/8,000 sec	1/125 sec
9	1/16,000 sec	PWC (pulse width control)

TABLE 8.	Electronic Sh	utter Speeds
----------	---------------	--------------

With VINIT high (CC1), the CCD keeps discharging. With an active low pulse to VINIT, the camera resets and purges the charge momentarily. Then it starts integrating for the period of shutter control set by either an external pulse width or internal shutter control. Progressive scanning permits a full 2048 lines of vertical resolution, as compared to a conventional CCD camera which captures only half the vertical lines per shutter.

8.4 Integration

The CCD imager of the TM-4100GE can be exposed for longer than the normal scan timing of 1/200 sec. This integration feature provides extra sensitivity for dark-environment applications. The progressive scan imager permits a full frame of resolution in non-interlace format. Integration is achieved by controlling CC2 Camera Control line through the Gigabit Ethernet cable to low (GND) or providing pulse-width control up to 1 sec. Please refer to Figure 26, "12P-02S Interface Cable (optional)," on page 37 for pin-out information on the 12-pin connector.

8.5 External Sync


The TM-4100GE accepts an external sync of standard HD and VD on CC3 and CC4 of the Gigabit Ethernet connector for general locking to an external source. The frequency requirement is shown in Table 8 on page 45. The tolerance is $\pm 2\%$ horizontal frequency.

8.6 Asynchronous Reset

The TM-4100GE camera includes three modes to control the asynchronous reset and shutter speed:

- Async No Shutter (recommended for strobe applications)
- Internal Shutter Speed Control
- External VINIT with Pulse Width (No-Delay Shutter) and ROI (read-out-inhibit)


TM-4100GE Hardware **PULDIX**®



8.6.1 Async No Shutter

Vinit trigger starts the first exposure period within one line $(1H = 32.5 \,\mu\text{sec.})$ and transfers the frame after a 9.5H exposure. After the first transfer, a new full frame exposure period (67.6 μ sec.) begins. Async No Shutter allows for strobe and back-to-back strobing (strobing both before the transfer gate and right after) applications.






8.6.2 Internal Shutter Speed Control

The video signal starts with internal VINIT. When the external VINIT pulse is applied, internal VINIT is latched to HD and the internal VINIT is delayed to set up the shutter speed period. The shutter speed is controlled by communication software from "1" to "8." Video output timing starts right after the internal VINIT and single shots, FDV is output at the internal VINIT timing.

8.6.3 External VINIT With Pulse Width (No-Delay Shutter) and ROI (Read-out Inhibit)

For multiple-camera applications such as 2D or 3D measurement and multi-angle inspection, simultaneous image capturing at an exact shutter timing for all cameras is a critical requirement. The TM-4100's asynchronous pulse-width control mode provides no-delay shutter as standard. Regardless of the internal pulse timing, the camera discharges at the VINIT leading edge and transfers charges at the trailing edge of the pulse. Even though each camera runs with slightly different H and data clock timing, the image capturing is exactly simultaneous.

FIGURE 32. No-Delay Shutter




The TM-4100GE camera also has read-out-inhibit control (ROI) to control the vertical clock start (Async Shutter #9). When ROI is low, V-clock is stopped and the transferred charges remain in the vertical shift registers, which work like CCD memory. When the ROI is high, it clocks out the CCD data. This helps a single frame grabber process multiple images in pipeline processing (sequential process).

Note: When the ROI function is not used, make sure that the INTEG/ROI CC2 input is kept logic high during Async. pulse width control mode.




FIGURE 33. Read-Out Inhibit



VINIT (External Pulse Width Control Trigger)

8.7 Dynamic Range Control



The typical interline transfer CCD has fixed noise levels based on dark current (thermal or KT noise), pattern noise, and the operating clock speed. In general, the level of the 40 MHz pixel clock CCD at room temperature is around 20 to 30 electrons. The maximum capacity of CCD charges is limited by the well capacity at saturation. The range is limited by the structure and the pixel size.

The TM-4100GE uses a CCD with 7.4 μ m x 7.4 μ m pixel and two-phase vertical shift register structure. The well capacity is 40,000 electrons. The theoretical dynamic range is 40,000:30 = 1333:1 (60 dB).

TM-4100GE Hardware **PULNIX**®

A typical CCD camera does not use the full dynamic range due to the nominal gain and the output specification such as RS-170. The typical CCD camera's gain is set at 16 to 22 dB and the RS-170 video level is 714 mV. Using 20 dB gain for the calculation, CCD output is limited to 714/10 = 71.4 mV.

Machine vision and outdoor applications cannot afford to miss image information behind the saturation, which is why the dynamic range adaptation is critical.

8.7.1 Programmable Look-Up Table (LUT) and Knee Control


The TM-4100GE has a built-in LUT (look-up table) for dynamic range control. At a specific gain setting, the offset (minimum level.... dark point) and A/D reference top voltage (maximum level... saturation point) are set to 10-bit A/D input so that the full dynamic range of the CCD is utilized at 10-bit references as the input and the LUT output is converted into 8-bit to adjust the gamma correction. Notice that the LUT (look-up table) is not available in the 10-bit grayscale mode.

The look-up table has two knee points (variable gamma selection) that allow the 10-bit input to be segmented into three regions. The look-up table selection can be made by knee curve direct input.




8.8 Camera Timing Charts

1. Video Output



2. External HD Locking & External VD Reset



>> External HD Locking

TM-4100GE Hardware **PULNIX**®

3. Async Reset

>> Async No Sh	nutter (async shutter 0)
External Vinit	aA
Discharge	
Transfer Gate	
Strobe	aD
FDV	▲ L → ▲ M →
>> Async Norma	al Shutter (async shutter 1-8) & Async No-delay Shutter (async shutter 9)
External Vinit	aE
Discharge	$ \begin{array}{c} 1 \\ \blacksquare \\$
Transfer Gate	
Strobe	
FDV	<i>aH</i> → <i>M</i> →
ROI/Integration	
>> Read-Out In	hibit (ROI, async shutter 9)
External Vinit	
Discharge	
Transfer Gate	
Strobe	
FDV	\rightarrow $aI \rightarrow M \rightarrow$
ROI/Integration	aJ aK



4. Video Output Order




TABLE 9. Video Output

Scan Area	Data	Horizontal (pixels)					Vertical (lines)					
	Clock	А	В	С	D	Е	K	L	Μ	Ν	0	
А	40MHz 25 ns	1300	276		0		2080	32	2048	0		
В				1024		0	1100	100	1000		0	
С						0	0	620	120	500	0	0
D							385	135	250			



Scan Area	Pixel	Horizontal		External HD Locking Timing (pixels)				Ver	tical		Vertical VD Reset Timing (lines)						
	Clock	Freq. (kHz)	Time (µsec)	eA	eB	eC	eD	eE	Freq. (Hz)	Time (msec)	eF	eG	еH	eI	eJ		
А			30.77 32.5			1300 100	00 1200	0	14.79	67.6		2080		2071	1		
В	40MHz 25ns	20.77		<20ns	1200				27.7	35.75	<2	1100	9	1091			
С		30.77			1300		100	1200	1200	1200	1200	0	49.63	20.15	~2	620	9
D									79.92	12.51		385		376			

 TABLE 10.
 External HD Locking and External VD Reset

TABLE 11.Async Reset

Scan Area	Async Reset Timing												
	aA (lines)	aB (µsec)	аC	۰D	۰E	aF	aG	aH (lines)		al dinag	aJ	aK	
			aC	aD	aE	(µsec)	(lines)	s1-8	s9	aI (lines	(sec)	(lines)	
А					s1-8: <1 line s9: <125ns			33	>aH & <ah +1<="" td=""><td rowspan="4">>aH + 1 & <ah +2<="" td=""><td rowspan="4"><1</td><td rowspan="4"><2</td></ah></td></ah>	>aH + 1 & <ah +2<="" td=""><td rowspan="4"><1</td><td rowspan="4"><2</td></ah>	<1	<2	
В	>1 & <2							101					
С								121					
D								136					



9 Troubleshooting

9.1 Problems and Solutions

Following are troubleshooting tips for common problems. In general, problems can easily be solved by following these instructions. If the following remedies fail to offer a solution to your problems, please contact a JAI PULNiX representative.

9.1.1 Symptom: No Video

Remedies: Check that the following are properly connected and operational.

- Power supplies
- Power cables
- Main power source
- Shutter control
- Async mode
- Lens
- Digital output cable
- Analog video cable

9.1.2 Symptom: Dark Video

Remedies: Check that the following are properly connected and operational.

- Shutter selection
- Iris opening on the lens

9.1.3 Symptom: Non-Synchronized Video

Remedies: Check that the following are properly connected and operational.

- Proper mode output
- Frame grabber software camera selection

TM-4100GE Hardware **PULNIX**®

9.2 Information and Support Resources

For further information and support:

Phone:	(408) 383-0300
	(800) 445-5444
Fax:	(408) 383-0301
E-mail:	imaging@jaipulnix.com
Mail:	JAI PULNiX, Inc.
	Sales Department
	625 River Oaks Parkway
	San Jose, CA 95134
	ATTN: Video Applications
Web Site:	www.jaipulnix.com



10 Appendix

10.1 Specifications


TABLE 12. TM-4100GE Camera Specifications Table

Feature	TM-4100GE						
Imager	1.2" progressive scan interline transfer CCD						
Active Area	15.15mm x 15.15mm						
Active Pixels	2048 (H) x 2048 (V)						
Cell Size	7.4μm x 7.4μm						
Display Mode (Active Pixels)	2048 (H) x 2048 (V) @ 15 Hz (full image) 2048 (H) x 1000 (V) @ 28 Hz (partial scan) 2048 (H) x 500 (V) @ 50Hz (partial scan) 2048 (H) x 250 (V) @ 80Hz (partial scan)						
Sync	Internal/External auto switch HD/VD, 4.0 Vp-p impedance 4.7 K ohms VD=14.79±2%, non-interlace HD=30.78kHz±2%						
Data Clock Output	40.00 MHz						
Resolution	Digital: 2048 (H) x 2048 (V), (Analog: over 800 TV lines (H) x 1600 TV lines (V))						
S/N Ratio	48dB min.						
Min. Illumination	Monochrome: 0.12 lux. Color: 0.8 lux. $f = 1.4$ (no shutter) @ 15 fps. Sensitivity: 31μ V/e-						
Video Output	Digital output: 8-bit x 2 / 10-bit x 2 Gigabit Ethernet (selectable at factory)						
Gamma	Programmable LUT (1.0 std.)						
Lens Mount	C-mount (use >1.2" format lenses or larger)						
Power Requirement	12V DC, ±10%, 600mA (typical at 25°C)						
Operating Temp.	-10°C to 50°C*						
Vibration	7 Grms (10Hz to 2000Hz) Random, 11 ms half sine						
Shock	70G						
Size (W x H x L)	51mm x 51mm x 85mm						
Weight	197 grams (6.9 oz.) without tripod						
Optional Functions							
Optional Accessories Power Cable Power Supply	12P-02S PD-12UUP series (includes power connector)						

*. Refer to Section 7.2.1 on page 35 for information on camera heat dissipation. Image quality will degrade with increasing temperature.



10.1.1 TM-4100GE Physical Dimensions



0000

ً

POWER

 \otimes


 \otimes

FIGURE 34. Physical Dimensions



10.1.2 Spectral Response





TM-4100GE Hardware **PULNIX**®

Page 60		
Appendix		







Imaging Products

JAI PULNIX, Inc. T 625 River Oaks Parkway T San Jose, CA 95134 F

Tel: 408-383-0300 Tel: 800-445-5444 Fax: 408-383-0301

Email: imaging@jaipulnix.com

www.jaipulnix.com